

E.1.4. mountain-drive - installation into eccentric bottom brackets (EBB)

For direct installation into an EBB's, there is no version of mountain-drive available. Please chamfer the eccentric insert of the bottom bracket as if it were the bottom bracket shell.