

### **E.2.2. speed-drive - installation into very narrow and wide botttom bracket shells**



For extrem narrow b.b. shells of 50 mm width (for example on fully faired cabin bikes) we deliver such a version.

There is also one available for extra wide b.b. shells of 100 mm width (Surly, some new E-bikes).

