

H.2.3. Lubrication of speed-drive "08"



Model "08" has a total of 10 Torx screws on the outer side (for T25 key). Remove one of them to fill in the lubricant. Please turn the crankarm until you can see a second hole underneath the first one to make sure, that the lubricant reaches the gears, which are behind the rotating planet carrier.